



**Application:** Any Standard 12-Volt Automotive System

**Part Includes**

- 1 - Relay
- 1 - Wiring Harness

## Hard Start 12 Volt Relay Kit



**Tools Needed**



**STEP 1.**

Refer to the enclosed wiring diagram, and plug configuration drawing to become familiar with wire and terminal locations before starting.

**STEP 2.**

Disconnect negative battery cable from battery.

**STEP 3.**

Select a location close to the starter to mount the relay. The relay should be mounted in an area with the terminals facing downward to prevent the entry of water or dirt into the relay. Drill a 1/8" hole where the relay is to be installed, and mount the relay with a sheet metal screw.

**STEP 4.**

Disconnect the ignition/starter switch wire (usually a red wire with a black stripe) from the start connector of the starter solenoid (connector is marked as #50 on solenoid cover), and attached it to the blue wire of the relay (terminal #85).

**STEP 5.**

Attach the black wire of the relay (terminal #87) to the start connector of the starter solenoid.

**STEP 6.**

Disconnect the battery cable from the starter solenoid terminal and attach the large red wire of the relay (terminal #30) to the starter solenoid terminal. Now re-attach the battery cable to the starter solenoid terminal.

**STEP 7.**

Attach the yellow wire from the relay (terminal #86) to a solid non-corroded ground connection.

**STEP 8.**

Tape all exposed connections. Use wire ties to secure the relay wires and route them away from potential damage areas such as exhaust manifolds, sharp corners or moving parts.

**STEP 9.**

Reconnect negative battery cable to battery.


Installation is now complete.




2900 North Third Street, Effingham, IL 62401  
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800  
[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)  
©Mid America Motorworks, Inc. All rights reserved.



# Hard Start Relay Kit Installation Instructions (cont.)



Side View of Starter



Terminal/Wire Color  
Locator

- Blue = Blue
- BL = Black
- RD = Red
- YW = Yellow
- RD/BL = Red w/Black stripe