

Suggested Installation Instructions for:
109-925 Hardtop/Targa Top Coat

HARDWARE INCLUDED:

- 8 - 5/16" x 1 1/2" BOLTS
- 4 - CASTERS
- 4 - 5/16" ACORN NUTS
- 8 - 5/16" FLAT WASHERS

Illustration below shows major components of the cart and position of the hardware for easy assembly.
Tools needed for assembly: 1/2" boxed end wrench or 1/2" socket with ratchet.

