



---

## Suggested Installation Instructions for: **301-519** Easy Install Style Headliner for 1968-77 Std and 1971-77 Super, Sedan Only

**Installation order:**

- #1 Door Post (Supplied sewn together. Separate before installation.)
- #2 Around Rear Window
- #3 Below 1/4 Windows
- #4 Main Section of Headliner

**NOTE: This Easy install Headliner does not replicate the O.E.M. Headliner. It features one less bow in the roof section and fewer seams around the rear window area.**

**This form is a general recommendation for installation. Mid America Motorworks recommends having headliners professionally installed.**

