



Suggested Installation Instructions for Floor Pan Jack Points:

303-582, 303-583, 303-584, 303-585, 303-586, 309-516

314-021, 378-381, 378-389, 378-841, and 390-605

Because your Jack Point has been removed for shipping you will now need to re-install it, which requires a simple welding operation. Please see diagram for the exact attachment location. As shown, the unit must be welded on both the top and bottom of your floor pan. On convertibles, the jack point is built into the reinforcement rails, so you may simply discard the enclosed jack point.

Important: Jack Point *MUST* be welded in place, no other method of attachment is acceptable.

