



Suggested Installation Instructions for 307-002 Taillight Conversion

1. Attach complete housing to fender
2. Remove 4 Phillips screws and separate lens from housing
3. In order to connect wires to the proper connectors, you must first remove the bulb holder.



- A. 2 tabs are located at the bottom of the bulb holder. Carefully pry one of these tabs to the side while gently pulling up, then repeat on the second tab. Both should detach easily with this procedure.
4. Once the bulb holder has been removed, follow the simple wiring instructions, below.
 5. To re-install bulb holder, make sure to fit each tab at the top BEFORE pushing on the bottom of the tab.

Wiring Instructions:

Attach original lamp harness leads to the proper terminals indicated in the diagram.

Note: due to the different number and type of bulb sockets in this unit, you will need to acquire and install a standard (1157/2057) dual element (brake/tail) bulb in the middle socket, as illustrated.

