

MID AMERICA



MOTORWORKS

PURSUE YOUR PASSION HERE

Suggested Installation Instructions for **313-469**, Super Beetle Strut Tie-Bar

1. Position car on level ground. Do not jack up car.
2. Loosen the three mounting nuts that retain the strut assembly to the car body. Taking care not to distract the strut assembly position, remove the mount nuts and install proper strut tie-bar mount bracket.
3. Apply above procedure on opposite side of car.
4. Assemble helm-joints to crossbar. One helm is left hand thread and one is right hand thread. Include supplied jam nut on right hand thread helm joint. Adjust helms to position tie-bar into mount brackets
5. Upon final assembly, position washers on either side of helm on the inside of bracket tabs and one each at bolt head and nut.