



Suggested Installation Instructions for: **336-136 Quick Release Deck Lid Pin Kit**

DIRECTIONS FOR SAFE AND PROPER INSTALLATION

- Step 1. Apply penetrating oil (WD-40*, Triflow*) to deck lid hinge pin assemblies.
- Step 2. Using a narrow punch, carefully remove the hinge pin from one hinge assembly. Always move the pin from the center outward. Place a small strip of tape along the leading edge of the deck lid to protect the paint.
- Step 3. With the pin removed, carefully drill the hinge assembly with a 1/4" drill from inside to outside.
- Step 4. Open the safety bail on the Quick Release Pin and insert the pin from the inside out. Put safety bail on pin to secure hinge.
- Step 5. Repeat all above steps for the other side.