



Suggested Installation Instructions for Product Number:**375-569****Btl 1949-1977, Spr 1971-1979 Door Hinge Screw Kit**

1. Remove door panel.
2. Locate Phillips head screws to be removed in door jamb area, and spray with a Penetrating oil. (One is behind Black plastic plug.)
3. Use an impact screw driver and loosen screws.
4. Before removing screws completely, locate hinge rivets in door panel area and drill these rivets using a drill no larger than replacement screws.
5. Now place the door on a work surface for hinge replacement.
6. Secure hinge in vise and drill side that mounts to door. Holes in hinge must be drilled to accept countersunk screws in kit.
7. Place new hinges on door (make sure you have correct hinge for location) and mount with new screw kit. Use lock washer & nut on back side of hinge.
8. Re-attach to car using original fasteners in door jamb area.

Note: Original hinges were riveted to doors.