



Part Number

Application: 1958-1962, 1963-1967, 1968-1975, 1986-1996 Corvette

600-366 600-368

600-370 600-372

Hardtop Cover



Tools Needed

Part Includes

1 - Hard Top Cover

Your new Hardtop Cover is designed to protect the hardtop from general scratches and grime while the top is in storage. Its easy hook and loop tab closure system make it easy to slip on and attach the flaps.

This cover is **NOT** designed or intended to be used for protection from rain or other heavy forms of moisture or condensation. It is also **NOT** designed to protect the top from heavy impacts or punctures through the fabric.

CAUTION: Your hardtop is a delicate part of your Corvette. It can be awkward to handle the top. It is suggested that you have help in holding the top while the cover is being positioned. Once the cover is on, store the covered top in a secure area off the ground or concrete floor to avoid damage from water, animals, etc.



DIRECTIONS FOR SAFE AND PROPER INSTALLATION

STEP 1.

Unfold the cover and locate the word "FRONT" stenciled on the cover.

STEP 2.

Slip the cover over the front windshield side of the hardtop so that the word "FRONT" will be on the exterior side of the hardtop. Position the cover completely over the hardtop.

STEP 3.

Fasten the hook and loop tabs around the bottom and sides to completely enclose the hardtop inside the cover.

STEP 4.

Your cover should now be in proper position. If it is not, check the tension and adjustment at the various locations of attachment.



MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



600-366 600-368
600-370 600-372

Hardtop Cover (cont.)

CLEANING INSTRUCTIONS

STEP 1.

Your new hardtop cover can be washed in **WARM WATER** with **MILD SOAP** and rinsed in **WARM** or **COLD WATER**.

STEP 2.

For best results, wash and rinse over a chair, fence or clothes line and dry naturally.

STEP 3.

If your climate requires mechanical drying, **BE SURE THE DRYER IS ON AIR DRY. DO NOT USE HEAT** as this may deform the shape of the cover and not allow a good fit on the hardtop.