

---

## Suggested Installation Instructions for 600-696, 1991-1996 Curved Front Plate Cover

1. Remove original panel from license plate area.
2. If necessary, notch or drill license plate where screws will go.
3. Install license plate in position.
4. Install clear plastic lens cover by using your original screws, or with the provided Phillips Head screws.

### Tips:

- Use a #1 Phillips screwdriver (it is smaller in diameter).
- Lay a credit card or small piece of plastic on lip of lower screw holes to protect paint.

