



Suggested Installation Instructions for:
**601-024, 1989-1995 Convertible/
1991-1995 Coupe Third Brake Light Bulb**

1989-95 Convertible & 1991-95 Coupe (Non
ZR-1 CHMSL (Center High-Mounted Stop
Lamp)

To access the bulb, remove the license plate and reach up behind the lens assembly and push the socket's lock tab down. Turn the socket counterclockwise and remove the socket from the lens assembly. The wire should be long enough to allow you to bring the socket into sight to change the bulb.

- 1-Center High Mounted Stop Lamp Rear Body Harness Assembly
- 2-Center High Mounted Stop Lamp Assembly
- 3-Rear Fascia
- 4-Bolt

