



Pursue your passion here

P.O. Box 1368 • Effingham, IL 62401 • Worldwide: 217-540-4200 • FAX: 217-540-4800
Call Toll-Free U.S. & Canada 800-500-1500 • Web: www.mamotorworks.com • E-mail: mail@mamotorworks.com

Suggested Installation Instructions for Product Number for: **601-547, 1984-1989 Corvette Horn Relay**

The horn relay is located behind the driver information panel in the center dash above the radio control head. To access the relay remove the bezel covering the center dash.

DIRECTIONS FOR SAFE AND PROPER INSTALLATION

- Step 1: Remove the two Phillips screws holding the cluster bezel to the dash at the right side of the cluster. Then remove the top and bottom Phillips screws.
- Step 2: After the bezel is removed, remove the three 7 mm screws holding the information panel to the dash. Pull the panel toward you carefully and unplug it from the dash. Let it hang down out of the way, making sure it does not scratch the radio control head.
- Step 3: The horn relay connector has two black wires in one terminal, one green, and one red wire.
- Step 4: Unclip the old relay from the metal clip.
- Step 5: Install the new relay and reassemble components by reversing the order of the above procedures.

