



## Suggested Installation Instructions for: 601-863, 1984-1996 Headlight Protector

### PREPARATION

NOTE: Preparation and installation of Headlight Protectors requires temperature to be above 50°F. DO NOT WASH THE VEHICLE FOR 48 HOURS AFTER APPLICATION OF PROTECTORS TO ALLOW THE GLUE TO SET.

- 1) Thoroughly clean the lamp. Ensure that all road film is cleaned off.
- 2) Make sure your hands are clean, and dry the lamp with a lint-free cloth.
- 3) Warm the Headlight Protectors with a hair dryer, your car's heater or the headlight itself, making the protector more pliable and easy to install.

### INSTALLATION

NOTE: Our Headlight Protectors have been custom cut to fit around the alignment tabs on the headlight (small peaks of glass). Be sure to position the protector correctly before removing the backing paper.

- 1) Peel off backing paper from half of one of the Headlight Protector.
- 2) Starting at one edge of the headlight, using moderate pressure, press the Headlight Protector in a sweeping motion across the headlight with one hand. Remove the remaining backing paper with the other hand and repeat the process for the remaining half.
- 3) Press out any large air bubbles to the edges of the lens. Smaller air bubbles will eventually disappear with use of headlights.
- 4) Repeat steps 1-3 for each headlight bulb.