



Part Number

**602-015
602-017
602-023
647-749**

Application: 1968-1976 C3 Corvette

Windshield Header Molding



Tools Needed



Part Includes

1 - Windshield Header Molding

Every effort has been made to ensure the highest possible quality in regard to the fit, texture, appearance, and longevity of this Windshield Header Molding. By following these installation instructions you can be assured of a trouble-free installation that will enhance the interior of your Corvette for years to come.

STEP 1.

Inspect the header molding you have received. Verify it is the correct year, color and body style, coupe or convertible, for your Corvette.

STEP 2.

With a Phillips screwdriver, remove the four screws that hold the sunvisor pins to the windshield header bar. Two screws are located on the header molding and two are on the pillar post. Remove the visors from the car.

STEP 3.

With a Phillips screwdriver, remove the remaining six screws that retain the header molding. Four are located along the bottom edge, close to the windshield, and two are located on the surface where the visor pin is mounted, on each end. With the screws out, remove the old header molding from the car.

STEP 4.

Place your new header molding in position on the windshield frame. Be sure it fits properly at both ends where it meets the pillar post and around the rear view mirror bracket. If your car is a convertible, it must also fit around the center latch for the top. If your car is a coupe, it must fit around the center T-bar for the roof.

STEP 5.

Using an awl, poke a small hole in the vinyl and foam of the header molding at the 8 places where screws go through the molding. When creating these holes, align the awl with the screw holes in the windshield frame.

CAUTION: Don't try to poke the awl the whole way through the molding. There is an inner support that must be drilled.

STEP 6.

Remove the molding from the car and with an electric drill and 1/8" drill bit, drill the 8 holes through the metal support inside the molding at the positions you have marked with the awl.

STEP 7.

Place the header molding back in position and replace the six screws that secure it to the windshield frame.

STEP 8.

Place your visors back in position and replace the screws that hold the visor pins to the header molding and pillar post and your installation is complete.



MAMotorworks



Midamotorworks



blog.autotainment.com

**17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com**

©Mid America Motorworks, Inc. All rights reserved.