



Application: Corvette 2000-2004

Part Includes

1 - Scratch Guards

Scratch Guards



Tools Needed

DIRECTIONS FOR SAFE AND PROPER APPLICATION

STEP 1.

Clean and dry area where guards are to be installed with plain water and a dry towel. Avoid using cleaners which contain anti-static components as they will keep scratch guards from adhering. Package contains one pair.

STEP 2.

Peel apart the guards (they are stuck together for protection).

STEP 3.

Guards can be removed and reinstalled as often as you wish, as they are static cling.



MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.