



Application: Corvette 1997-2004

Part Includes

1 - Pair of Splash Guards

Splash Guards



Tools Needed



STEP 1.

Clean wheel openings where splash guards are to be attached.

STEP 2.

Lay out splash guards to separate lefts from rights. Place the splash guard with the matte finish side out to distinguish lefts from rights.

STEP 3.

Remove the three black hex screws on the front inner fender panel of the wheel opening. Reinstall the screws with the splash guards in place. From the rear of the car, look at the alignment of the splash guard prior to tightening to ensure it is hanging straight. Repeat this procedure for the opposite side.

STEP 4.

Hold the rear splash guard up in position on the appropriate side of the car. Remove the 7mm hex screw that aligns with the center hole on the splash guard. Install the splash guard, and tighten screw until splash guard is held in place. From rear of car, look at the alignment of the splash guard prior to tightening to ensure it is hanging straight. Using a pencil or felt tipped marker, mark the locations of the two remaining holes in the rear guard and remove guard from car. **MAKE SURE SPLASH GUARDS ARE HANGING STRAIGHT PRIOR TO MARKING.** Drill two 1/4" holes where you have marked their locations. It may be necessary to remove the rear wheels to gain access to the inner fenders for drilling. Always support car on jack stands when working under car. Reinstall splash guard with the 7mm screw. Insert supplied nylon panel fasteners into the holes you drilled and reinstall wheel. Repeat procedure for other side.

CARE INSTRUCTIONS: Use mild soap and water to clean the splash guards and then apply a plastic and rubber dressing.



MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.