



Suggested Installation Instructions for:
609-051, 1992-1996 Intake Air Temperature Sensor Relocating Kit

Kit includes: 1 Sensor
 1 Harness
 1 Rubber Grommet
 2 Wire Ties

1. Remove keys from ignition or disconnect battery for safety.
2. Remove wiring harness from sensor at location #1. Leave original sensor in place.
3. Connect new extension harness into disconnected harness.
4. Drill a 7/8" hole in air intake system at general area of #2 in diagram.
NOTE: A wood worker's spade bit works well.
5. Install sensor into grommet. Carefully start one side of grommet into the hole you drilled in the air intake system. Using a straight screwdriver, carefully work grommet lip into hole until completely seated. Rotate sensor in grommet to insure the grommet/sensor assembly is fully seated.
6. Connect harness to sensor. Reconnect battery. Relocating is now completed.

