

MID AMERICA



MOTORWORKS

Pursue your passion here

**Suggested Installation Instructions for:
609-209, 1981-1991 Dyna-Mod HEI Distributor Module**

1. Carefully wipe clean the distributor housing surface onto which the module will be mounted.
2. Apply a liberal coat of grease from the enclosed tube onto the module flat mounting surface.
3. This special silicone grease acts to conduct heat away from the module.
4. Attach the module to the housing with the two screws and lockwashers.
5. Connect the pick-up coil leads to the module.
6. Attach the connector to the module.