



Suggested Installation Instructions for:
609-463, 1962-1974 Tach/Speedometer Gear 90° Adapter

INSTALLATION INSTRUCTIONS:

1. Insert the short end of Drive Pin into adapter (*Illust. A*)
2. Unscrew tach cable fitting from distributor gear bushing and pull tach cable out of the way. This is a good time to remove the bushing to check and lube the drive gear in the distributor. Replace gear and bushing.
3. Insert adaptor into coupler and tighten nut.
4. Re-attach the tach cable to the adaptor. Test for correct tach operation. *Use a good grade of automotive grease to periodically lubricate the adaptor by means of its grease zerk. (Do not overgrease as grease could work its way into Speedo/Tach head and cause damage.)*

For use on Speedometer Cables:

1. Disconnect speedometer cable from transmission.
2. Attach adaptor to transmission. Pivot to achieve best clearance.
3. Screw cable into adaptor.

