



**Suggested Installation Instructions for:
609-709, 1984-1996 Gas Door Boot Drain Kit**

Tools Needed:

T-15 Screwdriver

1/2" punch or bit/drill

VERY IMPORTANT: DURING THIS INSTALLATION, DO NOT SMOKE OR HAVE SPARKS OR OPEN FLAME NEAR WORK AREA—YOU ARE WORKING NEAR GASOLINE AND ITS VAPORS!!!

- 1) Remove gas door assembly by removing (4) T-15 screws, (two in front, two in back).
- 2) Again, DO NOT SMOKE OR WORK NEAR OPEN FLAME. Remove gas cap.
- 3) If you have a workbench and vise available, we recommend removing the boot for easier drilling. If not, remove the license plate for a better view during in-car drilling (and drain hose routing in Step 5). Replace gas cap before drilling to prevent contaminants from getting into the tank. In the lower left corner of the boot, use a punch or drill to make a 1/2" hole.
- 4) Reinstall the boot (if removed), and insert the drain hose into the new hole.
- 5) Route the drain hose to the left, clearing any wiring or tubing.
- 6) Use the sealant strips included with kit to seal the grommet to the boot. Use one under the grommet/between the boot, and one on the bottom of the boot/top of drain hose.
- 7) Once drain hose is sealed and properly routed, use included tie strap to affix the new drain hose. Be sure not to constrict the hose.
- 8) Reinstall license plate (if removed) and gas door assembly.