



Suggested Installation Instructions for:

609-717, 1963-1967 Gas Guard

609-719, 1968-1977 Gas Guard

609-721, 1978-1982 Gas Guard

1. Center the ears of the Gas Guard with existing screws in bezel. Remove screws that line up with holes in Gas Guard.
2. Place Gas Guard in position, add washers and insert screws. Tighten to fit.
3. Fold Gas Guard up and in. Additional trimming may be required for a completely accurate door lid closure.

NOTE: Mid America Gas Guard is made of the toughest space-age material available. It will not fail under normal conditions. It must be noted that gasoline may attack the paint insignia and cannot be guaranteed.

