



Application: Corvette 1994-1996

Part Includes

- 1 - Front Air Coupler
- 1 - Medium Hose Clamp
- 1 - Large Hose Clamp

Front Air Coupler



Tools Needed



OPTIONAL: One can remove the entire air cleaner for ease of installation, if desired. To remove the existing couplers as a unit: front and rear, follow steps 1-4.

STEP 1.

Unplug the mass air flow sensor.

STEP 2.

Unplug the manifold air temperature sensor.

STEP 3.

Loosen clamps.

STEP 4.

Remove whole unit.

STEP 5.

Remove manifold air temperature sensor from old coupler and insert into the new coupler.

STEP 6.

Carefully remove the mass air flow sensor clamps. Note: These can be saved for later use if desired.

STEP 7.

Remove one coupler at a time and replace in same position, then tighten clamps.

STEP 8.

Mount rear coupler into throat of throttle body.

STEP 9.

Mount front coupler into throat of air cleaner.

STEP 10

Make final adjustments, then tighten clamps.

STEP 11.

Plug the mass air flow sensor and manifold air temperature sensor back into the hole on the coupler. **NOTE TO 1995-96 OWNERS:** A sharp object or awl should be used to drill a small hole just large enough for the vacuum line to fit through tightly. The hole should also be in stock location.



MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.