



**Application:** Corvette 1990-1993

**Part Includes**

- 1 - Air Intake Power Coupler
- 1 - #60 Hose Clamp
- 1 - #104 Hose Clamp

## Air Coupler



**Tools Needed**



**STEP 1.**

Loosen clamps at front and rear of original coupler.

**NOTE: POSITION OF ORIGINAL CLAMPS FOR INSTALLATION OF NEW COUPLER.**

**STEP 2.**

Remove sensor on passenger side of coupler.

**STEP 3.**

Remove original coupler.

**STEP 4.**

Rub a light coat of lubricant over the lip on each end and pre-fit the new coupler.

**STEP 5.**

Drill a small diameter hole in the side of the new coupler, the same size and location as on the original coupler.

**STEP 6.**

Insert new coupler in the air cleaner, sliding forward as far as possible.

**STEP 7.**

Slide unit in place and mount coupler to throttle body.

**STEP 8.**

Mount air cleaner in place before tightening clamps on coupler ends.

**STEP 9.**

Tighten coupler end clamps.

**STEP 10.**

Install sensor in side of coupler and reconnect harness.

Optional: You can remove the air cleaner as a whole unit for ease of installation if desired.



MAMotorworks



Midamotorworks



blog.autotainment.com

**17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**www.mamotorworks.com • mail@mamotorworks.com**

©Mid America Motorworks, Inc. All rights reserved.



## **Air Coupler**

### **REMOVAL OF AIR CLEANER**

#### **STEP 1.**

Remove the two outside knobs on top of the air cleaner.

#### **STEP 2.**

Slightly lift air cleaner.

### **INSTALLATION TIPS:**

- Pre-fit unit once or twice
- Lube ends with silicone grease
- Use of a hair dryer or a heat gun will help soften coupler
- Tighten air cleaner lid before coupler clamps
- Now is a good time to change air filter
- Lube threads on air cleaner knobs
- Don't cross thread knobs on air cleaner lid