



Application: Corvette 1997-2004

Part Includes

- 4 - Flame Design Taillight Grilles
- 8 - Replacement Screws
- 8 - White Button Sockets
- 8 - Chrome Cap Covers

Flame Taillight Grilles



Tools Needed



Your new taillight grilles are designed to fit over your factory taillight lenses, utilizing the same OE hole locations. These grilles are stackable and you can install up to 3 sets stacking one on top of another using the replacement screws provided.

STEP 1.

Remove all eight factory screws from the taillights. NOTE: These screws will not be reused.

STEP 2.

Carefully place each taillight cover into position. Do this slowly so that you do not scratch your paint. (If you feel more comfortable, you can tape the painted area around your taillights using masking tape before installing your new stainless covers.) NOTE: The lamps tend to move, so if you use something smaller in diameter than the screws like a "small" Phillips screwdriver to align everything and then hold it in place prior to installing the new screws, it will make getting the screws started properly much easier. Once your cover or covers are in position, place two of the replacement screws provided through the white button sockets (provided) and fasten securely, being careful not to over tighten.

STEP 3.

Snap on chrome screw cap covers (provided).

STEP 4.

If your kit includes the third brake light cover, you will need to clean your third brake light lens first with household rubbing alcohol and let dry. Swipe once with the adhesive promoter pack provided. Hold the brake light cover and gently form by hand so that it conforms to and takes the shape of your brake light lens without forcing. Peel the red liner from your new cover and carefully place into position. Press firmly to set. Keep dry for 24 hours. NOTE: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching it. Then, wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.



MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.