



Application: Corvette 1997-2004

Part Includes

- 1 – Pair of Side Cove Screens
- 1 – Alcohol Swab Packet

Side Cove Screens, Pair



Tools Needed



STEP 1.

Park Corvette on a level surface and set parking brake.

STEP 2.

Loosen lug nuts on front wheels.

STEP 3.

Follow factory instructions for jacking up front of vehicle.

STEP 4.

Place jack stands as recommended by factory or owner's manual.

STEP 5.

Remove lug nuts and front wheels.

STEP 6.

Remove push pin retainers from the top and sides of the inner fender liner. Remove the 7mm screws to gain access to the inner side vent area.

STEP 7.

Pull liner out of the way to access side cove.

STEP 8.

Open alcohol swab packet and wipe down edges to provide clean surface for new tape.

STEP 9.

Align new screen in cove area as desired.

STEP 10.

Remove new double-stick tape backing and press down to secure screen in place. Adjust as desired.

STEP 11.

Reinstall inner fender trim with 7mm fasteners.

STEP 12.

Align inner liner and reinstall push pin retainers.



MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



612-169

Side Cove Screens, Pair

STEP 13.

Move to the other side and repeat above operations.

STEP 14.

Reinstall front wheels and hand-tighten lug nuts.

STEP 15.

Remove jack stands.

STEP 16.

Lower Corvette and torque lug nuts to factory specs.