



Suggested Installation Instructions for Product Numbers: 619-418, 619-426, 1997-2004 C5 Sound Deadener

DIRECTIONS FOR SAFE AND PROPER APPLICATION

Procedure:

- Step 1. Remove the carpet and any remaining padding (noting the factory position) from your interior.
- Step 2. Position your new insulation for best fit, mark the perimeter of each piece.
- Step 3. Install each piece of insulation, using enough adhesive (we recommend our spray adhesive # 119010) to keep the pieces from moving once installed.
- Step 4. Reinstall your carpeting in the same order as you removed it.

