



Suggested Installation Instructions for Product Number:**634-366, 2006-2009 Z06 Stainless Hood Vent Grille****648-196, 2006-2009 Z06 Stainless Hood Vent Grille****Count on Mid America Motorworks for all your Corvette Parts and Corvette Accessories**

PARTS INCLUDED:

- 1-Stainless Hood Vent Grille w/attachment tape
- 1-Adhesive Promoter Pack
- 1-Strip of attachment Tape

1. Carefully remove the black factory hood vent grille bezel from the hood opening. The factory hood vent bezel simply snaps in place however it does have a small square of double face attachment tape securing the bezel from flying out at high speeds. This tape will have to be removed from the factory bezel and replaced with fresh attachment tape provided. Simply rub the square of tape off with thumb then swipe the area once with the adhesive promoter provided. Then set the new piece of tape into position and press firmly to set.
2. Prepare the surface of the factory grille that you exposed behind the bezel by scrubbing it first with household rubbing alcohol to remove any dirt then swipe the area once with the adhesive promoter provided.
3. Once preparations have been properly made place your new grille into the opening to familiarize yourself with its position. Make sure that the new grille sits high enough so that the black factory bezel will cover around it. Once you have a good idea of how it is placed simply peel the release liner from the back of the stainless grille and press firmly into position.
4. With the stainless grille installed prepare the hood opening for the black factory bezel by cleaning off any remaining old attachment tape and then swiping it once with the adhesive promoter provided. Once this is done remove the red release liner from your new attachment tape on your factory bezel then snap the factory bezel back into place pressing firmly to set the tape. Do not get wet for 24 hours.

