



**Part Includes**

1 - Component

## Touch-Up Paint Pen



### Tools Needed



Search: **Paint**

[www.mamotorworks.com](http://www.mamotorworks.com)

**STEP 1.**

Fill tube 1/2-3/4 full with paint.

**STEP 2.**

Assemble in order shown at right.

**STEP 3.**

Shake well. To dispense, press tip.

**STEP 4.**

Recap after use.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.