



**Application:** 1968-1977 Volkswagen Standard Beetle Sedan  
1971-1977 Volkswagen Super Beetle Sedan  
1968-1973 Volkswagen Type 3

**Part Includes**

- 1 - Driver Side Mirror
- 1 - Mirror to body seal

## Exterior Mirror - Driver Side



**Tools Needed**



**NOTE:** If your vehicle is already equipped with Exterior Mirrors simply remove the original mirrors and install new units directly in their place.

**NOTE:** Due to a much thicker chrome coating than the original VW mirror, it may be necessary to chase (clean) the threads before installation. A tight fit is normal.

**STEP 1.**

Properly position supplied template on the door.

**STEP 2.**

With center punch and light hammer tap an indent into your door skin on the X.

**STEP 3.**

Roll door window down entirely then drill a 1/8" pilot hole where you made your mark.

**STEP 4.**

Now drill your pilot hole out to a final size of 5/8".

**STEP 5.**

Roll window back up and remove interior door panel and trim. This will give you access to install the mirror nut on the inside of the door skin.

**STEP 6.**

Insert threaded portion of mirror base in 5/8" hole.

**STEP 7.**

Install nut and tighten securely, making sure that the mirror base is straight.

**STEP 8.**

Reinstall door panel, shut door and adjust mirror for best vision.

*See reverse for template >*



aircooledvws



@acvwpassion



MAMotorworksACVWPassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



# Exterior Mirrors Template

306-152

Driver Side

*Vent Window Post*

Punch Here



Body Line

Passenger Side

Punch Here



*Vent Window Post*

Body Line