



**Application:** 1968–1977 Standard Beetle, 1971–1977 Super Beetle  
SEDAN ONLY. Will not fit Convertibles

**Part Includes**

2 – Sunvisor Assemblies

## Beetle Sedan Sunvisors



**Tools Needed**



**STEP 1.**

Loosen the mounting screws and remove visors completely with brackets.

NOTE: Save screws for mounting new visors.

**STEP 2.**

Match your new visors with the old ones to determine if there is a difference between driver and passenger sides.

NOTE: Some models do have the same visor pattern on each side and some do not.

**STEP 3.**

If you need to extend the length of the mounting rods they can both be turned back and forth and pulled out or pushed in to match your application.

**STEP 4.**

Install new sun visors.



aircooledvws



@acvwpassion



MAMotorworksACVWPassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.