



Application: 1977-1982 Corvette



Search: **Boots**
www.mamotorworks.com

Part Includes
1 - Shift Boot

Leather Shifter Boot



Tools Needed



DIRECTIONS FOR SAFE AND PROPER APPLICATION

STEP 1.

Inspect the shift boot you have received. Make sure it is the correct year and color.

STEP 2.

Park the vehicle in a level spot and set the parking brake.

STEP 3.

Remove the screws that hold the carpeted panels to the sides of the shifter console and remove the panels.

STEP 4.

With the socket set, remove the 4 bolts that hold the black plastic shift console plate to the shifter console. Two are located along the front edge and two at the rear edge of the shift console plate.

STEP 5.

Disconnect the lighter and any switches from the underside of the shift console plate.

STEP 6.

Remove the knob, spring and lock-out assembly from the top of the shifter.

STEP 7.

Tilt the rear of the shift console plate up until the shift boot clears the shifter stem.

STEP 8.

Push the shift boot down through the shifter console plate so it is inside out and remove the 4 screws that hold the boot to the plate. Remove the old boot.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

STEP 9.

Place the new boot in position on the plate and mark the location of the 4 retaining screws. Remove the boot and drill the 4 holes you have marked using the 1/8" drill bit.

STEP 10.

Place the boot back in position and install the 4 retaining screws.

STEP 11.

Lower the plate with the new shift boot installed back into position and connect the lighter and all switches to the underside of the shift console plate.

STEP 12.

Fasten the shift console plate in position by replacing the 4 bolts that hold it to the shift console.

STEP 13.

Put the spring, lock-out assembly and shifter knob back on to the shifter.

STEP 14.

Place the carpeted side panels in position and replace the retaining screws and your installation is complete.

NOTE

If holes do not align with your shift console it is better to drill new holes. Do not try to force into place.