



Application: Corvette 1968-1982

Part Includes

1 - Pair of Nip Chips

Nip Chips



Tools Needed



PREPARATION

Clean area that Nip Chip will protect of all dirt and remove any wax residue with simple rubbing alcohol. Wipe area dry before installation.

NOTE: Before installing clear Nip Chips, remove all fingerprints with a damp tissue or chamois.

INSTALLATION

STEP 1.

Remove Phillips head screw on Rocker Panel, just in front of the rear wheel, Illustration (A).

STEP 2.

Slide Nip Chip behind Rocker Panel, so that the hole in the Nip Chip lines up with the hole the Phillips screw left. Replace the Rocker Panel screw, (MAKE SURE NOT TO OVERTIGHTEN).

STEP 3.

Position the Nip Chip so that the extension piece rides on the inside of the Wheel Well of the car, Illustration (B). Place Double Stick Tape Dots in desired positions to secure the upper part of the Nip Chip.



A

B



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.