



**Application:** 1997-2004

## Bezel Retrofit Kit



### Tools Needed



### Part Includes

- 2- Plastic Gloves
- 1-Alcohol Wipe
- 1-Textured Bezel
- 1-Sandpaper
- 1-Clear for Colored Bezels
- 1-Black for Black Bezels

**NOTE:** do not install in direct sunlight, as the adhesive may set up too fast (less than 85 seconds). Make sure any cracks on your Bezel are as even as possible so the new Bezel has a good fit. Do not use under 50 degrees.


Wear gloves supplied in kit to protect skin from adhesive.

### STEP 1.

Use the alcohol wipe provided to clean the top of the broken Bezel of cleaners, protectants, etc., and bottom of the new Bezel for a good adhesive bond. (VERY IMPORTANT! CLEAN WELL!!) On the bottom of the bezel cover, scuff up the smooth surface with coarse sandpaper in kit, then clean with alcohol wipe.

### STEP 2.

Place the new Bezel cover over the existing Bezel and check for a good fit. It completely covers the broken Bezel down to the dash pad almost all installs. (use painters tape on top of new Bezel for protection from adhesive during install) Don't tape front of Bezel down to windshield, so tape can be removed.



### STEP 3.

Place a piece of paper, cloth, etc. over the projector glass, and use blue painters tape to go around your broken Bezel on the dash pad for protection from adhesive drips or excess from sides during install (Get as close as possible with tape).



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



## Description (cont.)

### STEP 4.

Put a drop of the adhesive around the entire bottom of the new Bezel zigzagging about 1 inch apart. Now carefully place the new Bezel over the old cracked Bezel and apply firm pressure while properly aligning it dispersing the adhesive. Keep pressure on bezel for about 1 minute. (remember, the adhesive sets in up to 85 seconds depending on the conditions, humidity, temp, etc. do not use if under 50 degrees or in direct sunlight.) You don't need much adhesive, too much will prolong set up time. If weather is cold, run heater to warm up interior before installation.



### STEP 5.

Release pressure, your new Bezel should be in place. CAREFULLY wipe off any excess adhesive, if any, on blue tape and remove tape from dash pad and bezel, and remove projector glass protection.

### STEP 6.

Allow 24 hours for adhesive to fully cure.