

**KIT**

**INCLUDES:**

**(11) 8-32 X 1/8" SOCKET HEAD SCREWS.**

**YOU WILL ALSO NEED: # 29 DRILL BIT, 8-32 TAP,  
5/16" DRILL BIT, 3/32" ALLEN WRENCH.**

### **INSTALLATION INSTRUCTIONS**

1. Remove complete glove box door from car by removing 3 screws from hinge to door.
2. Viewing back of door, note rivets holding door together
3. Use #29 drill bit & drill through center of rivet head, 7/32" deep, without disturbing outer face Of door frame. (Use drill press for best results)
4. with a 5/16" drill bit, drill down through rivet heads (but not the back of the door) until you have removed the rivet head, allowing the frame & two plates to come free.
5. Thread the holes with an 8-32" tap.
6. Place new aluminum panel in glove box frame, and place glove box door back over plate on pins.
7. Install new socket head screws with an allen wrench.
8. For that "all original" final touch, lightly drill out the heads of the socket screws so they resemble factory rivets. Just a touch of the drill will do the trick.
9. Paint back of the door and screw heads, semi-gloss black.