



Application: 1997-2004 Corvette

Part Includes

- 1 - Stainless Throttle Body Cover
- 1 - Chrome Cap
- 1 - Adhesive Promoter Packet
- 1 - Velcro Attachment Bracket

Power Steering & Throttle Body Cover



Tools Needed



Search: **Power Steering**
www.mamotorworks.com

STEP 1.

Remove the power steering cap.

STEP 2.

Loosen the 10-mm bolt directly atop the throttle body.

STEP 3.

Place the Velcro attachment bracket over the loosened bolt so that the tab faces the rear of the engine and tighten down. Place your new cover over the power steering reservoir and take a look at the overall fit make any adjustments by hand if needed. Replace power steering cap.

STEP 4.

You have been supplied with a chrome decorative power steering cap cover. In order to install this cover simply scrub the top of the factory cap with household rubbing alcohol to remove all dirt and grime. Then swipe the top of the cap once with the adhesive promoter snap tube provided. Remove the Velcro attachment cookie from the underside of the chrome cap peel the release liner from the cookie and firmly press into place on top of the prepared factory cap. Then simply set the chrome cap cover in place.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.