



Application: 2005-2013 Corvette

Part Includes

- 1 - Stainless Steel Lettering Set
- 1 - Tube of Adhesion Promoter

Stainless Steel Rear Script



Tools Needed



Search: **Decals**
www.mamotorworks.com

DIRECTIONS FOR SAFE AND PROPER APPLICATION

STEP 1.

Use supplied alcohol pads (in square packets) to thoroughly clean script indentation. Dry with clean cloth.

STEP 2.

Pre-position new script to see how it fits.

STEP 3.

NOTE: It is necessary to slightly "bow" the long pieces to fit the contour of the bumper.

STEP 4.

Remove backing film from the new script.

STEP 5.

Apply "adhesion promoter" that is in the breakable tube, to the back of the adhesive on letters.

STEP 6.

Position script in indentation and press in place.

STEP 7.

For maximum adhesion, do not wash Corvette for 48 hours.

STEP 8.

Clean script with soft, clean cloth to preserve finish.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.