



Application: 2005-2007

Part Includes

1 - Component

Stock Stainless Door Sill



Tools Needed



Search: **Protectors**
www.mamotorworks.com

PLEASE NOTE: THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOORSILLS CANNOT BE REMOVED WITHOUT DAMAGING THE PART. PLEASE NOTE YOUR CAR WILL NOT BE DAMAGED IN ANY WAY.

Your new doorsills come to you with a protective liner. DO NOT remove the liner until step 4.

STEP 1.

Thoroughly clean the surface first with soap and water then with household isopropyl alcohol.

STEP 2.

Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.

STEP 3.

When you are satisfied with the fit, remove the red liner from the attachment tape, reposition your new sill and press firmly.

IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE SILLS INTO PLACE. THE ATTACHMENT TAPE IS VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!

YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!

STEP 4.

Once in place remove the protective liner. Repeat steps 1-5 for the opposite doorsill.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.