

INSTRUCTION SHEET

Part Number

619-527

Part Includes

Application: Corvette

- 1-Stainless Brake Booster Cover
- 2-Chrome Nut Covers 121 NC





Tools Needed

Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.

STEP 1.

Remove the two 10mm nuts securing the water tank and lift it out of its position and rest it over the alternator temporarily.

STEP 2.

Remove the vacuum line and the two nuts securing the master cylinder. Pull the master forward off the two bolt studs.

STEP 3.

Slide the new booster cover over the master base and line up the holes in the booster cover with the holes in the master.

STEP 4.

Reposition the master onto the bolt studs as you carefully allow the new cover to slip over the factory booster. At the same time you will need to effectively align the new cover over the booster stud bolts. Jostle the assembly into position so as to allow you to FINGER TIGHTEN (DO NOT OVERTIGHTEN) the two master cylinder nuts. Remove the protective liner and tighten down (DO NOT OVERTIGHTEN) the master and cover.

STEP 5.

You have been provided with two decorative chrome nut covers. Apply a small dab of 100% clear household silicone to the covers and install them over the two factory bolts to finish the installation. 6. Replace and secure the factory water tank.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner. SEE ENCLOSED CARE SHEET!

Related Parts

Related Item | Related Item | Related Item





MAMotorworks



Midamotorworks



blog.autotainment.com

17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • mail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.



INSTRUCTION SHEET

Part Number

000-000

Description (cont.)

Toll Free: 800.500.1500 • Worldwide: 217.540.4200 • www.mamotorworks.com • mail@mamotorworks.com

Page 2