

# **INSTRUCTION SHEET**

**Part Number** 

621-918

Part Includes 2-Door Sills

**Application:** 2005–2013

# **Door Sill Installation**









#### STEP 1.

Using masking tape, mark the two ends of your existing Sill decals to use as locating points for the new Door Sill Plates.

# STEP 2.

Remove the existing Sill decals using a hair dryer to loosen adhesive.

## STEP 3.

Once decals are removed, wipe area clean with window cleaner or alcohol.

## STEP 4.

Remove adhesive backing and install new Door Sills using your tape marks for positioning.

NOTE: Each Sill is marked LT, and RT, and should be positioned with the flag emblem towards the front of the car.







Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.