



Application: 2005-2013 Corvette

Part Includes

- 4 - Stainless Taillight Covers
- 2 - Packs of Adhesive Molding
- 4 - 3/8"x22 Adhesive Molding
- 1 - Replacement Kit

Stainless Taillight Covers



Tools Needed



Search: **Taillight**
www.mamotorworks.com

VERY IMPORTANT!! PLEASE READ ENTIRE INSTRUCTIONS BEFORE BEGINNING THIS INSTALLATION!!

STEP 1.

Clean each of the taillight openings first with rubbing alcohol to remove any dirt and wax. Then swipe the painted area closest to the lens with one of the adhesive promoter packs provided.

STEP 2.

You have been supplied with four lengths of molding. Starting at the left or right side of the lens tab at the top of each light place this molding directly to the painted surface, as you pull the release liner from the back of the molding, working your way around to the opposite side pressing firmly to set. Trim away any excess molding. PLEASE NOTE: Make sure that the molding attaches to the painted surface and that it rest against the taillight lens. This strip of molding creates a bondable surface for the new covers to attach to.

STEP 3.

Now that all four taillights have been fitted with the attachable molding, swipe all four molding strips with the second pack of adhesive promoter provided. Carefully (DO NOT SCRATCH YOUR PAINT!! You may elect to put some masking tape on your painted surface area) set each taillight cover in place and check the overall shape. Although the new covers come to you preformed it will be necessary to hand form each cover so that it matches the placement of the molding at both sides ONLY without forcing it. It should lay flat to the left and right sides of your molding attachment strip only NOT TO THE TOP OR BOTTOM. This can easily be done by gently shaping each cover with both hands horizontally until the desired shape is accomplished.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

STEP 4.

Once you are satisfied with the fit of each lens simply peel the red liner from the back of the cover and carefully place each cover into position making sure that your lines are all equally placed horizontally (See Pictures) pressing firmly at the sides **ONLY**. Doing this will set your new covers to the molding strip installed earlier. **NOTE:** Although the back of your covers are fully taped they are designed to mount to the left and right side of the molding strip **ONLY!** **DO NOT ATTEMPT TO PUSH IN THE CENTERS** or the top and bottom of the lens as this will distort the final installation!

STEP 5.

REPLACEMENT KIT INCLUDED: We have provided you with a replacement kit should you ever need to change one of your light bulbs use this kit to reinstall your lens cover!