



Application: Corvette 2005-2013 C6

Part Includes

1 - Component

Rear Bumper Apron



Tools Needed



Search: **Bumper**
www.mamotorworks.com

STEP 1.

Drape the bib over the rear of the car. Position the center part of the bib with the sponge rubber sewn inside, with the center of the car next to the trench between the weather striping and rear body panel, (Illus. A). Press the sponge rubber part of the bib down into that trench area, (it will wedge snugly). Then moving to the left, lay the bound edge of the bib in the trench until you reach the tab sewn at the corner of the bib, (this tab has soft Velcro sewn onto the under side of the material). Tuck the tab into the recessed area, (Illus. B). Repeat this step moving to the right side of the hatch opening. Note how each tab lays against the side wall of the recessed area.



ILLUS. A

STEP 2.

Once you have the bib positioned correctly; pull the tab on each end back, and install the 1" adhesive backed Velcro pieces, by removing the backing and sticking to the side wall of the recessed area as shown (Illus. C). The soft Velcro sewn on the back of these tabs will attach to the Velcro you are sticking down, to hold each end of the bib secure.



ILLUS. B

STEP 3.

To remove; simply pull the bib tabs loose; pull the center part out of the trench and fold up the bib with the black side out, like it was when you received it for storage. If folded properly, it will fit in one of the rear storage compartments.

Care: To clean the bib, wipe down with a damp cloth and mild soap, and let dry before refolding.



ILLUS. C



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.