



# INSTRUCTION SHEET

Part Number

**628-305**

Application: Corvette 2005-2013



Search: **Exterior Lighting**  
[www.mamotorworks.com](http://www.mamotorworks.com)

## Side Marker Trim, Set of 4

### Part Includes

- 4 - Side Marker Trim pieces
- 2 - Alcohol pads



### Tools Needed

#### STEP 1.

Remove any greasy detail dressing or wax by using the supplied alcohol pads or Windex. If you were furnished with a 3M adhesive promoting pen or wipe, apply that material after cleaning and just before applying your item. The 3M promoter should not touch areas of your car that will not be covered by your new trim. (Larger rim pieces should be dry fitted before removing the adhesive release paper so that you are comfortable with the fit once you're prepared to install.)

#### STEP 2.

After dry fitting, carefully peel back the release paper and apply your trim item. Hold for a minimum of 10 seconds. Use 3M blue painter's masking tape to help continue the application of pressure for several hours, before removing any top surface clear protection.

**NOTE: 3M ADHESIVE PROVIDES APPROXIMATELY 30% OF ITS POTENTIAL HOLD AFTER ONE HOUR AND 70% AFTER 12 HOURS. PARTS WITH LARGER ADHESIVE CONTACT AREAS DO NOT REQUIRE THIS EXTRA ATTENTION.**



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401  
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800  
[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)  
©Mid America Motorworks, Inc. All rights reserved.