



Application: C6 Corvette

Part Includes

1 - Component

Side Cove Screen Kits



Tools Needed



Search: **Screen**

www.mamotorworks.com

DIRECTIONS IF WHEELS ARE NOT REMOVED

STEP 1.

Turn wheel completely to the left.

STEP 2.

Remove the Push In Fasteners from the wheel well liner.

STEP 3.

Pull out on the liner and reach in and separate the inner cover liner that is double taped to the side of the fender.

STEP 4.

Reach through the inner liner and once you reach through the inner liner, your hand will be in the mounting area.

STEP 5.

With the tape backing still on the cove screen, fit the screen to the mounting area for a test fitment and make sure the screen is turned in the matching direction.

STEP 6.

Clean the mounting area with alcohol pads. Remove the backing and then apply the adhesive promoter if supplied.

STEP 7.

With one hand in the mounting area behind the fender, and the other hand outside of the area, align the screen and press firmly to the mounting area.

STEP 8.

Keep applying pressure to the screen to make sure that the screen is secured properly in place.

STEP 9.

When mounted properly, re-install the inner liner and wheel well liner to its original position.

STEP 10.

Re-install the Push Pin Fasteners and repeat these same steps for the other side.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.