

Application: 1997–2004

INSTRUCTION SHEET

Part Number



Part Includes

1 - Component

Hood Light Switch



Tools Needed

STEP 1.

Allow engine to cool.

STEP 2.

Open hood.

STEP 3.

Locate hood light harness near passenger side hood hinge.

STEP 4.

Disconnect lower end of harness by using small screwdriver to gently pry up on connector clip. Unclip and separate connection. (Photo A.)

STEP 5.

Use split tip screwdriver or pry tool to gently pry up and remove 4 plastic push-in hood blanket retainers near hood light. Lift hood blanket only enough to gain access to upper harness connection at light. (Photo B.)

STEP 6.

Disconnect upper end of stock light harness at light by unclipping and wiggling connector apart, the same as with the lower end. (Photo C.)

STEP 7.

Remove and retain stock harness.

STEP 8.

Install new harness. Switch with conduit cover goes near lower connection. Connect upper end to hood light. Route harness same as stock harness. Keep clear of RH hood hinge. (Photo D.)

STEP 9.

Snap together lower connection.

STEP 10.

Check operation of switch. If it operates correctly, re-install hood blanket retainers by aligning holes and pressing in place.

STEP 11.

Check that harness does not interfere with hood hinge operation. If desired, harness may be secured in position with supplied nylon tie straps.





MidAmericaMotorworks

CorvettePassion

2900 North Third Street, Effingham, IL 62401 800.500.1500 · Worldwide: 217.540.4200 · FAX: 217.540.4800 www.mamotorworks.com · generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.











