



Application: 2014-2019 C7 Corvette

Part Includes

- 1 - Stainless Cylinder Cover w/ Velcro Attachment Cookie
- 1 - Adhesive Promoter Packet
- 1 - 3/4" Chrome Cap Cover w/ Velcro Attachment Cookie

Brake Master Cylinder Cover



Tools Needed



Search: **Underhood**
www.mamotorworks.com

The cylinder cover comes with a clear protective liner. This liner will help to keep new parts clean during installation. Removal of the liner is instructed in Step 3.

STEP 1.

Thoroughly clean the top surface of the reservoir and the fluid cap with household rubbing alcohol to remove any road grime and dirt. Swipe the areas with the adhesive promoter provided. Remove the factory fluid cap.

STEP 2.

The new cover has a Velcro attachment cookie mounted to the underside of it. Remove the cookie half and install it directly to the prepared surface of the reservoir.

STEP 3.

Place the new cover over the reservoir, pressing down gently to set in position. Replace the factory fluid cap and remove the protective liner.

STEP 4.

The chrome cap provided also has a Velcro attachment cookie. Remove the cookie half and mount it to the factory fluid cap, pressing firmly to set. Press the chrome cap in place.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.