



Application: 2006-2013 C6 Corvette

Part Includes

- 1 - Stainless Dry Sump Oil Tank Cover
- 1 - 3/4" Self Tapping Screw
- 1 - 1" Thumb Scrwe
- 1 - Support Bracket w/ Velcro
- 1 - Zip Tie

Dry Sump Oil Tank Cover



Tools Needed



Search: *Oil*
www.mamotorworks.com

LEAVE THE LINER IN PLACE UNTIL THE INSTALLATION IS COMPLETE TO PREVENT FINGER PRINTS AND/OR POSSIBLE SCRATCHES DURING INSTALLATION.

STEP 1.

Place the cover into position to check the fit and also to take a look at the large wire harness. The cover is notched for this harness; however, since it is a wire harness, it will need to be manipulated so that it will run through the notch in such a way as to not allow the new cover to chafe the harness. Use the zip tie to help secure the harness to the required position.

STEP 2.

Remove the wiper cowl gasket and examine the end of the cover to determine the location of the covers support bracket. This bracket has been designed to be secured by the factory wiper cowl clip located closest to the covers end. Pull the factory clip off the wiper cowl. Hold the support bracket in place and force the clip back onto the cowl securing the support bracket.

STEP 3.

With the bracket in place, position the new cover and mark the thumb screw hole to the hoods safety hook platform with a marker. Remove the cover and drill a 5/32 pilot hole at that location. Use the single pilot screw provided to create that thread into the pilot hole by using a screw gun to run the screw in and out of the hole a few times to create a nice thread path for the thumb screw. Do not try to thread the thumb screw in before this procedure because this will damage the thumb screw. If the thumb screw binds, run the pilot screw through again until the installation of the thumb screw is nice and free moving.

STEP 4.

Set the new cover into place and secure it with the thumb screw provided. Remove the protective liner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.