



Application: 2006-2013 C6 Corvette

Part Includes

- 1 - Stainless Plenum Cover
- 2 - Strips of Velcro Attachment Tape
- 1 - Pack of Adhesive Promoter
- 1 - Test Kit

Plenum Cover



Tools Needed



Search: **Engine**
www.mamotorworks.com

LEAVE THE LINER IN PLACE UNTIL THE INSTALLATION IS COMPLETE TO PREVENT FINGER PRINTS AND/OR POSSIBLE SCRATCHES DURING INSTALLATION.

STEP 1.

Surface Preparation: The new cover is designed to attach to the existing stock fuel rail covers via Velcro Tape. **NOTE:** If silicone treatments have previously been applied to the fuel rail covers, refer to the special preparation instructions. If silicone treatments have not been applied, then continue by first removing all road dirt and grime with soap and water. Then, scrub the fuel rail covers along the entire most inner corner with household isopropyl alcohol (this is where the new plenum cover will sit). Let dry, then wipe the same area with the adhesive promoter (provided).

STEP 2.

The new cover has 2 Velcro strips of attachment tape on the underside. Remove the hook side from both strips and set aside for a moment. Place the new cover on top of the factory fuel rail covers and line up so that it appears flush with the back gasket ridge.

STEP 3.

Place a length of masking tape on either side of the new plenum cover directly onto both factory fuel rail covers. Doing this will indicate where the new cover sits.

STEP 4.

Apply the Velcro hook strips along the inside edge of the tape just placed (the hook strips will be under the new plenum cover). Press firmly to set and remove the masking tape.

STEP 5.

Install the new cover by pressing into position. It may be necessary to slightly lift and nudge the new cover in order to achieve a straight fit.

Tech Tip: Although this procedure should not be necessary with a proper installation, 2 or 3 rivets may be applied through the hook side of the Velcro into the factory fuel rails on both sides to insure that the Velcro stays in place.

NOTE: Care must be taken when cleaning the cover. It is a good idea to lightly dust the cover with a clean soft cloth first in order to prevent any particles from scratching it. Then, swipe (using a new clean soft cloth) with a good quality streak free glass cleaner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.