



Application: 2005-2013 C6 Corvette

Part Includes

- 2 - Perforated Side Vents
- 6 - Stainless Spears
- 2 - Adhesive Promoter Packs
- 2 - Lengths of Chrome Trim (Optional)
- 1 - Paper Template

Side Vent Spears



Tools Needed



Search: **Vent**

www.mamotorworks.com

STEP 1.

Prepare the surface with soap and water to remove any road grime and dirt. Then, scrub the area to be mounted with rubbing alcohol. After the entire area is thoroughly cleaned, swipe the area with one of the adhesive promoter packs provided.

STEP 2.

A paper template for the suggested position of each spear has been provided. Cut the template along the lines indicated. Place the template along the fender's edge so that it lines up with the very bottom of the vent hole. The three cutouts created will evenly and correctly position each of the spears. The spears are marked starting from top to bottom (1P, 2P, & 3P for the passenger's side and 1D, 2D, & 3D for the driver's side). Before beginning permanent installation, set each spear into place to get acquainted with its position. Each spear tip is designed to fit into the vent hole and to just touch the vent grille. **NOTE:** They are not designed to have full contact with the side vents as this will create an unsightly gap between the fender and the spear.

STEP 3.

Peel and stick all 3 spears into place. Press firmly to set a nice bond. **DO NOT GET THE SPEARS WET FOR 24 HOURS.**

STEP 4.

Remove the template and repeat steps 1-3 for the opposite side.

STEP 5.

Two lengths of chrome trim (optional) has been provided. This trim has been supplied to be placed at the outer edge of the vent opening to add a finished appearance. Clean the vent ridge with rubbing alcohol, then swipe with the adhesive promoter provided. Once preparation is complete, peel the red release liner from the precut trim and set in place, pressing firmly to set.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.