

Application: 1997–2013 C5 Corvette





INSTRUCTION SHEET

Part Number



Part Includes

- 4 3/4" Cap-Water Tank
- 1 3/4" Cap-Washer Fluid
- 1 3/4" Cap-Brake Fluid
- - 1 1/2" Cap-Power Steering
 - 1 Angle Cap-Oil
 - 5 Attachment Cookies
 - 1 Pack Adhesive Promoter

STEP 1.

Thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering and clutch if so equipped. Scrub them with alcohol to remove any surface contaminants, then swipe the tops with the adhesive promoter provided.

STEP 2.

2" furry Velcro attachment cookies have been provided for each cap except the clutch fluid which will only have butyl putty on the small chrome cap to hold both the cover and cap on. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.


STEP 3.

The factory wind shield washer fluid cap will need to be trimmed slightly in order for the new cover to sit centered. To do this, snip the finger tab as well as the attachment strap off the cap with scissors.

STEP 4.

The set will contain a cap cover that is angled for the oil cap and a thinner cover for the power steering cap. The remaining covers in the kit are for all other factory caps. Simply set them in place.





@CorvettePassion

MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....

CorvettePassion