



Application: 1997-2004 C5 Corvette

Part Includes

- 1 - Stainless Fuse Box Cover
- 1 - 2" Stainless Screw Cover w/ Velcro
- 1 - Adhesive Promoter Pack
- 1 - Velcro Attachment Dot

Fuse Box Cover



Tools Needed



Search: **Fuse**
www.mamotorworks.com

STEP 1.

Remove fuse relay cover.

STEP 2.

Turn over the fuse relay cover and remove attachment screw by spreading the slits holding screw in place.

STEP 3.

Slide off the positive battery post cover. This cover will not be reused. **NOTE:** This is attached to the fuse relay cover.

STEP 4.

Place a few dabs of household silicone to both ends of the cover and place the cover over the fuse relay cover.

STEP 5.

Snap attachment screw back in and screw cover in place. A round screw cover has been supplied. Swipe the top of the attachment screw with the adhesive promoter provided and place the Velcro attachment dot directly to the screw head. Attach the 2" stainless screw cover in place. **NOTE:** This cover will need to be removed to gain access to the attachment screw.

NOTE: Care must be taken when cleaning the cover. Lightly dust the cover with a clean soft cloth first in order to prevent any particles from scratching it. Then, wipe (using a new clean soft cloth) with a good quality streak-free glass cleaner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.